





1 Tag-Geh- und Weckerwerk, 1 Schlüssel
1 day alarm movement, 1 key
Mouvement réveil 1 jour, 1 clef
Mecanismo de sonería, 1 día, 1 llave

Werk **001**
Movement **021**
Mouvement
Máquina



00-80-98.2

280




0-80-98.2

282



00-99.2

284



00-80-100.2

285



00-101.2

286



00-102.2

287



00-103.2

288



00-80-104.2

289

Werk
Movement
Mouvement
Máquina

001
021

1 Tag-Geh- und Weckerwerk, 1 Schlüssel
1 day alarm movement, 1 key
Mouvement réveil 1 jour, 1 clef
Mecanismo de sonería, 1 día, 1 llave



001 - 77.1

37



00 - 61.1
04 - 61.1

109, 110



101 - 62.2

40



101 - 63.1

41



101 - 80 - 12.1

43



101 - 80 - 79.1
04 - 80 - 79.1

42, 111



00 - 80 - 55.1

112



00 - 80 - 49.2

113



00 - 2.1

114



00 - 3.1

115



0975 - 7.1

116



0670 - 7.1

117




03 - 80 - 23.2

118



8 - 80 - 3.1

51



101 - 102/1.1

53



101 - 103/1.1

54



001 - 7.2

270



00 - 60 - 1.2

266



00 - 80 - 91.1

121



101 - 93/1.1

48



00 - 80 - 16.1

122



0670 - 80 - 16.2

123



0350 - 80 - 16.1

124



06061 - 80 - 16.2

262



0602 - 69.1

125



0602 - 71.1

126



1 Tag-Geh- und Weckerwerk, 1 Schlüssel
1 day alarm movement, 1 key
Mouvement réveil 1 jour, 1 clef
Mecanismo de sonería, 1 día, 1 llave

Werk 001
Movement 001
Mouvement 021
Máquina 021




00-80-1.1

90




0-80-1.1

92




00-80-25.2

94




001-80-30.1

96



001-80-54.2

97



00-97.2

276



00-58.1

99



00-59.1

100



00-80-34.1

101



00-80-36.1

102



00-80-38.1

103



00-80-40.2

278




00-80-42.2

105

101-44.1

27



00-80-64.2

279




51-66.2

277



00-67.1

107



001-80-20.1

31



101-17.1

33



101-80-10.2

34