

\*\*\*\*\* CAL. 1MXX MOV'T PART LIST \*\*\*\*\*  
 ORIGINAL PARTS, MADE IN JAPAN

<u>PART NAME</u>	<u>1L50</u>	<u>1M50</u>	<u>1M52</u>
BATTERY	280-340	280-340	280-340
BATTERY CONNECTOR	231-368	231-368	231-368
BATTERY INSULATOR	230-220	230-220	230-220
CALENDAR CORRECTOR INT. WHEEL	087-194	087-194	087-184
CALENDAR CORRECTOR LEVER	116-118	116-118	116-119
CALENDAR CORRECTOR WHEEL	213-410	213-410	213-410
CANNON PINION WITH DRV. WHEEL	028-282	028-282	028-282
CLUTCH WHEEL	064-790	064-790	064-790
COIL UNIT	246-181	246-181	246-181
DAIL GUARD	713-123	713-123	713-123
DATE DIAL DRIVING WHEEL	103-118	103-118	103-118
DATE DIAL GIB			178-240
DATE DIAL GUARD	293-113	293-113	293-113
DATE DIAL 1(DATE DISC FOR THE 1ST DIGI	108-C1XX	108-B9XX	108-F90
DATE DIAL 2 (DATE DISC FOR THE 2ND DIGI	108-C2XX	108-C0XX	108-G00
DATE JUMPER	109-660	109-660	109-660
DAY DIAL GIB	178-140	178-140	
DIAL GUARD RING	110-420	110-420	212-304
ELECTRONIC CIRCUIT UNIT	279-A450	279-A450	279-A457
FIFTH WHEEL AND PINION	084-700	084-700	084-700
FOURTH WHEEL AND PINION	023-323	023-323	023-323
HOUR WHEEL	075-454	075-454	075-509
INTERMEDIATE DATE WHEEL			087-232
LONG SETTING STEM(24.0 MM)	065-508	065-5080	065-508
MINUTE WHEEL AND PINION	072-121	072-121	072-121
ROTOR	285-175	285-175	285-175
SCREW	923-107	923-107	923-107
SCREW (2)	923-112	923-112	923-112
SCREW FOR DIAL GUARD(3)	929-510	929-510	929-510
SETTING LEVER	067-173	067-173	067-173
SETTING LEVER SPRING	077-135	077-135	077-135
SETTING STEM	065-505	065-505	065-505
SETTING WHEEL	076-640	076-640	076-640
SPACER FOR MAIN PLATE			226-413
SPACER FOR SETTING STEM	212-241	212-241	212-241
STATOR	190-152	190-152	190-152
THIRD WHEEL AND PINION	017-149	017-149	017-149
TRAIN WHEEL BRIDGE	701-E010	701-E000	701-E010
YOKE	071-136	071-136	071-136