

Calibre 1210

Ø23.80mm

Ht: 4.27mm

Train: 18.000

● Centre second

● Shock Proof

● 18 Jewels

Base Calibre 1210











Image	Rolex No.	Description
	114	Bridle
	116	Bridle
	118	Bridle
	120	Bridle
	121	Bridle
	122	Bridle
	131	Bridle
	134	Bridle
	165	Screw for bridle
	7490	Main plate











Image	Rolex No.	Description
	7492	Barrel bridge
	7493	Train wheel bridge
	7494	Balance bridge
	7500	Mainspring, strength standard
	7500-1	Mainspring, strength weak
	7501	Barrel arbor
	7502	Barrel with arbor
	7504	Centre wheel with cannon pinion
	7505	Jewel for centre wheel-upper
	7507	Third wheel
	7508	Jewel for third wheel-upper










Image	Rolex No.	Description
	7509	Jewel for third wheel-lower
	7512	Second wheel
	7513	Jewel for second wheel-upper
	7514	Jewel for second wheel-lower
	7517	Driving wheel over third wheel
	7518	Centre second pinion
	7519	Second pinion friction spring
	7520	Screw for second pinion friction spring
	7521	Escape wheel
	7522	Pallet bridge
	7524	Pallet fork
	7525	Pallet staff Ø 0.31mm
	7526	Pallet staff Ø 0.36mm
	7528	Entry pallet















Image	Rolex No.	Description
	7529	Exit pallet
	7532	Screw for: • Barrel bridge • Train wheel bridge • Balance bridge
	7534	Balance with Breguet hairspring, timed
	7537	Screw for balance
	7538	Screw for regulating the balance
	7544	Balance staff
	7545	Roller
	7548	Regulator
	7549	Winding stem
	7550	Winding pinion
	7551	Sliding pinion
	7552	Crown wheel
	7553	Crown wheel core
	7554	Crown wheel seating


Image	Rolex No.	Description
	7555	Screw for crown wheel core
	7556	Ratchet wheel
	7557	Screw for ratchet wheel
	7558	Click
	7559	Screw for click
	7560	Spring for click
	7561	Setting lever
	7562	Screw for setting lever
	7563	Jumper for setting lever
	7565	Yoke for sliding pinion
	7566	Spring for yoke
	7567	Setting wheel
	7568	Minute wheel
	7568-1	Stud for minute wheel
	7569	Cannon pinion ht. 2.23mm





















Image	Rolex No.	Description
	7570	Cannon pinion ht. 2.43mm
	7571	Hour wheel ht. 1.27mm
	7572	Hour wheel ht. 1.47mm
	7573	Screw for dial
	7577	Set of screws
	7578	Friction spring for hour wheel
	7610	Shock-absorber for balance-upper
	7611	Shock-absorber for balance-lower
	7622-1	Banking pin
	7845	Screw for pallet bridge
	7850	Jewel for pallet fork-upper /lower
	7856-1	Adjusting washer: 1/100
	7856-2	2/100
	7856-3	3/100
	7856-4	4/100
	7856-5	5/100

Image	Rolex No.	Description
	7863	Screw for stud
	7932	In-setting for balance-upper / lower
	7934	Spring with axle for in-setting for balance-upper /lower
	7936	In-setting for escape wheel-upper /lower
	7937	Cap jewel for escape wheel-upper /lower
	7938	Spring for in-setting for escape wheel-upper /lower
	55003	Screw for setting lever jumper
	95019-3	Cap jewel for balance-upper / lower